

FLOOR MODEL POS ASSEMBLY

POS Kit should include: LCD Screen & Mount, USB Flash Drive with video, Right & Left side panels, front header panel, & front logo. *Optional Pedestal*



Remove backing from Velcro on the side panel lips & attach the front header panel.

Remove backing from double-stick & place logo onto the front header panel.



Attach the LCD Screen to the Mount with built-in utensil holder.

Remove backing to double-stick the left & right sides of the unit. (Align to the top of the freezer. ****Do not block freezer door access****)



OPTIONAL- If applicable, place freezer onto pedestal.